

## ADLIB UPGRADE INSTRUCTIONS

IF YOUR CARD IS ALREADY ASSEMBLED, PLEASE REMOVE WIRES FROM

**L2, L4, L6, L7, L8, L1, L3, L5**

PLEASE SOLDER THE COMPONENTS IN THE FOLLOWING PLACES:



**L2, L4, L6, L7, L8**

BL03RN2R1P1A FERRITE BEAD



**L1, L3, L5**

ELC11D\_180uH\_1.3A CHOKE



**C15, C16, C17**

220nF CAPACITOR

**FOR BEST RESULTS PLEASE ALWAYS USE ANTISTATIC ESD SAFE GLOVES AT ALL TIMES.**