



DEFAULT SWITCH POSITIONS  
WORKS WITH MOST COMPUTERS

ROM ADDRESS (SWITCHES 1-3)

	0XC000	0XC400	0XC800	0XCC00	0XD000	0XD400	0XD800	0XDC00
SW1_1	OFF	OFF	OFF	OFF	ON	ON	ON	ON
SW1_2	OFF	OFF	ON	ON	OFF	OFF	ON	ON
SW1_3	OFF	ON	OFF	ON	OFF	ON	OFF	ON

IO PORT (SWITCHES 4-6)

	0X200	0X240	0X280	0X2C0	0X300	0X340	0X380	0X3C0
SW1_4	OFF	OFF	OFF	OFF	ON	ON	ON	ON
SW1_5	OFF	OFF	ON	ON	OFF	OFF	ON	ON
SW1_6	OFF	ON	OFF	ON	OFF	ON	OFF	ON

IMAGE FAMILY (SWITCHES 7-8)

	REGULAR	OLIVETTI & FRIENDS	BUGGY AMSTRAD DOS - FORCE CHS MODE	AT 1X XTIDE + 1 X "PLAIN" IDE, FULL MODE
SW1_7	OFF	ON	OFF	ON
SW1_8	OFF	OFF	ON	ON

